



2 bay Network Charger

Model: CHG 2N

SL Network Charger

Model: CHG 4N

Quick Guide

Kurzanleitung

Guide de démarrage rapide

Guida rapida

Instrucciones resumidas

Instruções resumidas

Beknopte gebruiksaanwijzing

Krótko instrukcja obsługi

Snabbguide

Kort vejledning

Рѣководство

Σύντομες οδηγίες

Kısa Kılavuz

Краткая инструкция

快速指南

快速使用指南

クイックガイド

요약 안내서

SENNHEISER



www.sennheiser.com/download


Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Printed in Germany, Publ. 01/24, 587458/A03


In the box

CHG 2N





OR




CHG 4N




+




Setup




Charging



Network Setup





LED Status



	= 100 %
	< 100 %
	< 66 %
	< 33 %
	Error
	Firmware Update (CHG 4N)
	Firmware Update (SL Handheld DW/ SL Bodypack DW)
	Not supported transmitter or firmware update required

Remote Control



Sennheiser Control Cockpit



<https://www.sennheiser.com/control-cockpit-software>